

## Door Closer - Adjustment


### *Adjusting Using Speed:*

There are two speeds: door closing speed and controlled speed.


Each is controlled by their own speed regulating screw.

Adjust the door closer speed (section No.1) with the No.1 speed regulating screw, and the controlled speed (section No. 2) with the No. 2 speed regulating screw.

Turn clockwise to reduce speed; counter-clockwise to increase speed.



### *Adjusting Section of Closing Speed*



To adjust closing speed of sliding door, locate 2 speed regulating screws on the door closer. Adjust as per diagram.

**Note:** exercise caution when adjusting. If the adjustment screws are screwed out too far it can cause damage to the O-ring inside and cause the cylinder to leak.